

Chromebook Startup Guide

Step 1: Plug your Chromebook into a power source on either side of the Chromebook.



Step 2: Press the power button to turn the Chromebook on




Step 3: Click the “Let’s Go” button

Step 4: Select and connect to your home network (The Chromebook will automatically connect to the school network)

Step 5: Log into your District-Provided Google Account

Step 6: Agree To Terms and Conditions




Getting started with Canvas


Step 1: Click the “Start” button in the bottom, left hand corner.




Step 2: Click on the Canvas App



Step 3: Click “Find My School”




Step 4: Under “What’s your school’s name?” type “USCSD,” then press enter.



Please Note!
As you type in USCSD, nothing will come up. Just hit the enter key, on the keyboard, after typing in USCSD.

Step 5: Login with your Network/Canvas Login



Every Student is required to complete the Chromebook training course, which is located in Canvas. To enter the course, Log into Canvas and accept the invitation at the top of page to access the course.

